




Megalight SOL LED360°

When ordering spare parts to Megalight lamps, always remember to give the following details:

- LED or Fluorescent model?
- The model of the lamp (Standard, Pipe or Tripo),
- Operating voltage of the lamp (24,42 or 230 VAC),
- The spare part order nr.

Order nr.	Prod. code	Name
2ASOL	202ASOL	SOL opal dome
2BSOL	202BSOL	O-ring for Opal dome, 180mm
4LEDBSOL	204BSOL	cover film SOL dome
5(24W)SOL	205A24WSOL	LED Module 24W SOL
6SOL	206SOL	base for SOL dome
8SOL	208SOL	Connector + cord SOL LED module
9aSOL	209ASOL	outer seal between dome base and hull
9bSOL	209ASOL	inside seal between dome base and hull
11+21b	211Y+221b	nylon end flange(hook) + rubber damper
12	212	seal between flange and hull
13	213	cable gland
14A	214A	cable 3x1,5 mm 10 m (NF) SCHUKO
15 (24W/230VAC)	2152324WL	LED driver 24W / 230 VAC
15 (24W/24-48VAC)	215244824WL	LED driver 24W / 24-48 VAC
16	216Y	nylon hull
19a	219A	230VAC socket SCHUKO
19b	219B	230VAC socket SCHUKO NF
19c	219C	socket EN60309(CEE309)
19s	219S	Socket SELV 24 or 42VAC
20	220	magnet 600 N M10
22a	222A	Plug SCHUKO
22b	222B	Plug CEE309
22s	222S	Plug SELV